



**SCHEMATIC WIRING DIAGRAM**  
**COMFORT PACK ELECTRIC**  
**A or B SERIES R22 5-10KW**

SERVICE MANUAL EDITION - 3/17/2022

BR - BLOWER RELAY  
CAP - DUAL CAPACITOR  
CC - COMPRESSOR CONTACTOR  
CFM - CONDENSER FAN MOTOR  
COMP - COMPRESSOR  
EBM - EVAPORATOR BLOWER MOTOR  
FS - FUSE  
HL - HIGH LIMIT SWITCH

HTR - ELECTRIC STRIP HEATER  
SEQ - SEQUENCER  
SF - SMART FAN CONTROL  
TB - TERMINAL BOARD  
TD - BLOWER TIME DELAY  
TDOM - TIME DELAY ON MAKE  
XFMR - TRANSFORMER