



**SCHEMATIC WIRING DIAGRAM
COMFORT PACK ELECTRIC
E SERIES R410A 5-10KW**

SERVICE MANUAL EDITION - 3/17/2022

BR - BLOWER RELAY
BCB - BLOWER CONTROL BOARD
CAP - DUAL CAPACITOR
CC - COMPRESSOR CONTACTOR
CFM - CONDENSER FAN MOTOR
COMP - COMPRESSOR
EBM - EVAPORATOR BLOWER MOTOR
FS - FUSE

LPS - LOW PRESSURE SWITCH
HL - HIGH LIMIT SWITCH
HSD - HARD START DEVICE
HTR - ELECTRIC STRIP HEATER
SEQ - SEQUENCER
TB - TERMINAL BOARD
TDOM - TIME DELAY ON MAKE
XFMER - TRANSFORMER