



SCHEMATIC WIRING DIAGRAM
COMFORT PACK ELECTRIC
U*1 SERIES R410A 5-10 KW

SERVICE MANUAL EDITION - 3/17/2022

BR - BLOWER RELAY
CAP - DUAL CAPACITOR
CC - COMPRESSOR CONTACTOR
CFM - CONDENSER FAN MOTOR
COMP - COMPRESSOR
EBM - EVAPORATOR BLOWER MOTOR
FS - FUSE
HC - HEATER CONTACTOR

LPS - LOW PRESSURE SWITCH
HL - HIGH LIMIT SWITCH
HTR - ELECTRIC STRIP HEATER
XFMR - TRANSFORMER
TB - TERMINAL BOARD
TD - BLOWER TIME DELAY
TDOM - TIME DELAY ON MAKE