



SCHEMATIC WIRING DIAGRAM
COMFORT PACK GAS
D SERIES R410A

SERVICE MANUAL EDITION - 5/3/2022

BR - BLOWER RELAY
CAP - DUAL CAPACITOR
CB - CONTROL BOARD
CBR - COOLING BLOWER RELAY
CC - COMPRESSOR CONTACTOR
CFM - CONDENSER FAN MOTOR
COMP - COMPRESSOR
DS - DOOR SWITCH

EBM - EVAPORATOR BLOWER MOTOR
FS - FLAME SENSOR
GV - GAS VALVE
HBR - HEATING BLOWER RELAY
HL - HIGH LIMIT SWITCH
IND - INDUCER MOTOR
LPS - LOW PRESSURE SWITCH
PS - PRESSURE SWITCH

RO - ROLLOUT SWITCH
SI - SPARK IGNITOR
TB - TERMINAL BOARD
XFMR - TRANSFORMER