



**SCHEMATIC WIRING DIAGRAM
COMFORT PACK GAS
U1 SERIES R410A**

SERVICE MANUAL EDITION - 5/3/2022

CAP - DUAL CAPACITOR
CB - CONTROL BOARD
CC - COMPRESSOR CONTACTOR
CFM - CONDENSER FAN MOTOR
COMP - COMPRESSOR
DS - DOOR SWITCH
EBM - EVAPORATOR BLOWER MOTOR
FS - FLAME SENSOR

GV - GAS VALVE
HL - HIGH LIMIT SWITCH
IND - INDUCER MOTOR
IR - INDUCER RELAY
LPS - LOW PRESSURE SWITCH
PS - PRESSURE SWITCH
RO - ROLLOUT SWITCH
SI - SPARK IGNITOR

TB - TERMINAL BOARD
XFMR - TRANSFORMER