

SCHEMATIC WIRING DIAGRAM
COMFORT PACK ELECTRIC
E SERIES R410A 15KW

SERVICE MANUAL EDITION - 3/17/2022

BR - BLOWER RELAY	LPS - LOW PRESSURE SWITCH
BCB - BLOWER CONTROL BOARD	HL - HIGH LIMIT SWITCH
CAP - DUAL CAPACITOR	HSD - HARD START DEVICE
CC - COMPRESSOR CONTACTOR	HTR - ELECTRIC STRIP HEATER
CFM - CONDENSER FAN MOTOR	SEQ - SEQUENCER
COMP - COMPRESSOR	TB - TERMINAL BOARD
EBM - EVAPORATOR BLOWER MOTOR	TDOM - TIME DELAY ON MAKE
FS - FUSE	XFMER - TRANSFORMER