

SCHEMATIC WIRING DIAGRAM
COMFORT PACK GAS
U3 SERIES R410A

SERVICE MANUAL EDITION - 5/3/2022

CAP - DUAL CAPACITOR
CB - CONTROL BOARD
CC - COMPRESSOR CONTACTOR
CFM - CONDENSER FAN MOTOR
COMP - COMPRESSOR
DS - DOOR SWITCH
EBM - EVAPORATOR BLOWER MOTOR
FS - FLAME SENSOR
GV - GAS VALVE
HL - HIGH LIMIT SWITCH
HPS - HIGH PRESSURE SWITCH
IND - INDUCER MOTOR
LPS - LOW PRESSURE SWITCH
PS - PRESSURE SWITCH
RO - ROLLOUT SWITCH
SI - SPARK IGNITOR
TB - TERMINAL BOARD
XFMER - TRANSFORMER